

PSTYLEMODE system variable

1778 GstarCAD MY /KW July 23, 2021 [System Variables](#) 0 2320

Function Description:

The **PSTYLEMODE** system variable is used to specify whether the current drawing is in color dependent plot style or named plot style.

(Read-Only)

Type : Integer

Saved in : Drawing

Initial value : 1

Range : 0,1

System Variable Value:

0 : the current drawing is in named plot style

1 : the current drawing is in color dependent plot style

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1778>