

# PUBLISHHATCH system variable

1783 GstarCAD MY /KW July 26, 2021 [System Variables](#) 0 2027

## Function Description:

The **PUBLISHHATCH** system variable is used to control whether hatch patterns of DWF or DWFx published is treated as a single object.

**Type** : Integer

**Saved in** : Registry

**Initial value** : 1

**Range** : 0,1

## System Variable Value:

**0** : when publish DWF or DWFx formats, hatch patterns group is treated as each single object

**1** : when publish DWF or DWFx formats, hatch patterns group is treated as a single object

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1783>