

SPLINESEGS system variable

1835 GstarCAD MY /KW July 27, 2021 [System Variables](#) 0 2454

Function Description:

The **SPLINESEGS** system variable is used to control the generated segment number for each spline-fit polyline which generated by Spline option of PEDIT command.

Type : Integer

Saved in : Drawing

Initial value : 8

Range : -32768 ~ 32767

Specifying it to be a negative value, it will use the absolute value of settings to generate segments, and then a fit-type curve is applied to those segments. The arc will be used as approximating segments for fit-type curves. If the specified number of segments is smaller, the arcs generated curves will be much smoother, but it may take a long time to generate curves.

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1835>