

# TDCREATE system variable

1860 GstarCAD MY /KW July 27, 2021 [System Variables](#) 0 2478

## Function Description:

The **TDCREATE** system variable is used to store the local time and date when creating a drawing.  
(Read-Only)

**Type** : Real

**Saved in** : Drawing

**Initial value** : Unknown

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1860>