

TDCREATE system variable

1860 GstarCAD MY /KW July 27, 2021 [System Variables](#) 0 2370

Function Description:

The **TDCREATE** system variable is used to store the local time and date when creating a drawing.
(Read-Only)

Type : Real

Saved in : Drawing

Initial value : Unknown

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1860>