

TEMPPREFIX system variable

1867 GstarCAD MY /KW July 27, 2021 [System Variables](#) 0 2823

Function Description:

The **TEMPPREFIX** system variable is used to store the file folder name with path separators for temporary files.

(Read-Only)

Type : Strings

Saved in : Not saved

Initial value : Unknown

The temporary file combined name and path length is limited to 255 characters.

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1867>