

# XDWGFADECTL system variable

1924 GstarCAD MY /KW July 28, 2021 [System Variables](#) 0 2475

## Function Description:

The **XDWGFADECTL** system variable is used to control the fade degree for all DWG xref objects.

**Type** : Integer

**Saved in** : Registry

**Initial value** : 50

**Range** : -90 ~ 90

## System Variable Value:

**0** : DWG xref objects do not fade

**>0** : when this value is a positive value, the fade degree is controlled by percentage up to 90%

**<0** : when this value is a negative value, DWG xref objects do not fade, but the value is kept and it could be converted by changing its symbol.

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1924>