

XLOADPATH system variable

1928 GstarCAD MY /KW July 28, 2021 [System Variables](#) 0 1995

Function Description:

The **XLOADPATH** system variable is used to create the path for store temporary copy of xref when demand-loading.

Type : Strings

Saved in : Registry

Initial value : Unknown

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1928>