

# XLOADPATH system variable

1928 GstarCAD MY /KW July 28, 2021 [System Variables](#) 0 2072

## Function Description:

The **XLOADPATH** system variable is used to create the path for store temporary copy of xref when demand-loading.

**Type** : Strings

**Saved in** : Registry

**Initial value** : Unknown

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1928>