## **ACISOUT** command

1951 GstarCAD MY /KW July 30, 2021 CAD Commands 0 1617

The **ACISOUT** command is used to export a body object, solid, or region to an ACIS file.

**Command Access:** 

**Command**: ACISOUT

**Command Prompts:** 

**Select object**: select the object and press ENTER

## **Function Description:**

If the selected object is not a solid or region object, it will be ignored and displays the "Create ACIS File" dialog box; inputting the file name to be created, the selected object will be exported to an ASCII file.

Online URL: <a href="https://www.kb2.gstarcad.com.my/article.php?id=1951">https://www.kb2.gstarcad.com.my/article.php?id=1951</a>