

# ACISOUT command

1951 GstarCAD MY /KW July 30, 2021 [CAD Commands](#) 0 2044

The **ACISOUT** command is used to export a body object, solid, or region to an ACIS file.

## **Command Access:**

**Command :** ACISOUT

## **Command Prompts:**

**Select object :** select the object and press ENTER

## **Function Description:**

If the selected object is not a solid or region object, it will be ignored and displays the “Create ACIS File” dialog box; inputting the file name to be created, the selected object will be exported to an ASCII file.

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=1951>