

BTRIM command

2019 GstarCAD MY /KW August 5, 2021 [CAD Commands](#) 0 2733

The **BTRIM** command use to trims objects with a block as a cutting boundary.


Command Access :

Command Entry : BTRIM

Menu : Express>Blocks>Trim to Nested Objects


Command line prompts as follow:

Select objects or <select all>: Select one or more blocks and press ENTER



Select the object to Trim or Shift-select to Extend or [Edge/Fence/Crossing/Project]:

Select object(s) or enter an option and press ENTER



Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=2019>