

BURST command

2020 GstarCAD MY /KW August 5, 2021 [CAD Commands](#) 0 2980

The **BURST** command is use to explode blocks, converting value of attributes to text objects.

Command Access :

Command : BURST

Menu : Express>Blocks>Explode Attributes to Text


Command line prompts as follows:

Select entities: Use an object selection method

For example:

Explode attributes and convert them to text objects.

1. Select a block containing two attributes:



2. Block exploded and attribute values converted to text:

