## **EATTEXT** command

## 2110 GstarCAD MY /KW August 12, 2021 CAD Commands 0 2416

The **EATTEXT** command is used to extracts drawing data and merges data from an external source to a data extraction table or external file.

## **Command Access:**


**Menu**: Tools > Data Extraction

**Command: DATAEXTRACTION/EATTEXT** 

## **Function Description:**

Exports object properties, block attributes, and drawing information to a data extraction table or to an external file.

The Data Extraction wizard is displayed.



Online URL: <a href="https://www.kb2.gstarcad.com.my/article.php?id=2110">https://www.kb2.gstarcad.com.my/article.php?id=2110</a>