

FIELD command

2125 GstarCAD MY /KW August 13, 2021 [CAD Commands](#) 0 1677

The **FIELD** command is used to create multiple texts with field. The text could automatically update as the field changing.

Command Access:

Ribbon : Insert > Data > Field

Menu : Insert > Field

Command : FIELD

Shortcut : right-click when editing text by In-place text editor and click "Insert Field"

Function Description:

The FIELD command could insert all kinds of formats to text except tolerance. The FIELDEVAL system variable and the UPDATEFIELD command could determine the field updating modes.

Field

Field category: All

Field names:

- Author
- Block Placeholder
- Comments
- Create Date
- Current Sheet Category
- Current Sheet Custom
- Current Sheet Description
- Current Sheet Issue Purpose
- Current Sheet Number
- Current Sheet Number And Title
- Current Sheet Revision Date
- Current Sheet Revision Number
- Current Sheet Set
- Current Sheet Set Custom
- Current Sheet Set Description
- Current Sheet Set Project Mile
- Current Sheet Set Project Number
- Current Sheet Set Project Name
- Current Sheet Set Project Phase

Author: ----

Format:

- (None)
- UPCASE
- lowercase
- First capital
- Title case

Field expression:

%<\AcVar Author \f ""%tc1">%

OK Cancel Help

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=2125>