## FIELD command

2125 GstarCAD MY /KW August 13, 2021 CAD Commands 0 1864

The **FIELD** command is used to create multiple texts with field. The text could automatically update as the field changing.

## **Command Access:**

Ribbon : Insert > Data > Field Menu : Insert > Field Command : FIELD Shortcut : right-click when editing text by In-place text editor and click "Insert Field"

## **Function Description:**

The FIELD command could insert all kinds of formats to text except tolerance. The FIELDEVAL system variable and the UPDATEFIELD command could determine the field updating modes.

Field	ĺ	X
Field <u>category:</u> Al Field <u>names:</u> Field <u>names:</u> Author Field <u>names:</u> Author BlockPlaceholder Comments CreateDate Current SheetCategory Current SheetCategory Current SheetCategory Current SheetCategory Current SheetCategory Current SheetCategory Current SheetCategory Current SheetCategory Current SheetCategory Current SheetSumpose Current SheetNumber Current SheetNumber And Tri Current Sheet Number And Tri Current Sheet Revision Date Current Sheet Revision Date Current Sheet Set Revision Numt Current Sheet Set Custom Current Sheet Set Descriptior Current Sheet Set Project Mile Current Sheet Set Project Nar Current Sheet Set Project Nar Current Sheet Set Project Nar Current Sheet Set Project Nar	Author:      Eomat:   (None)   UPCASE   lowercase   First capital   Title case	x
Field expression:		
%<\AcVar Author \f "%tc1">%		
	OK Cancel <u>H</u> elp	

Online URL: <u>https://www.kb2.gstarcad.com.my/article.php?id=2125</u>