

MSPACE command

2245 GstarCAD MY /KW August 19, 2021 [CAD Commands](#) 0 1335

The **MSPACE** command is used to switch from paper space to model space in a layout viewport.

Command Access:

Command : MSPACE

Function Description:

This command could be used in paper space and model space. Users could draw, design, and create 2D drawings and 3D model in model space. They could create a layout for printing in paper space. In layout, users could make the last viewport to be current by inputting "mspace" in command line, and then work in model space. They could also switch to model space by double-clicking the viewport.

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=2245>