TEXTTOFRONT command

The **TEXTTOFRONT** command is used to place text and annotation to the front of other objects.

Command Access:

Command : TEXTTOFRONT

Menu : Tools > Drawing order> Bring Annotations to Front> Text Objects Only

Command Prompts:

Bring to front [Text/Dimensions/Leaders/All] :

Relative Glossary:

Text:
Bring the text to the front of all other objects in drawing.
Dimensions:
Bring dimensions to the front of all other objects in drawing.
Leader:
Bring leaders to the front of all other objects.
All:
Bring all text, dimensions, and leaders to the front of all other objects.
Note: the text contained in block or external reference could not be separated and brought to front. As well multiple leader texts and text in table could not be brought to front.