

VPMIN command

2431 GstarCAD MY /KW August 25, 2021 [CAD Commands](#) 0 2476

The **VPMIN** command is used to restore the current viewport.

Command Access:

Command : VPMIN

Function Description:

The settings of circle center and scale factor will be restored as maximized before.

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=2431>