VSLIDE command

2435 GstarCAD MY /KW August 25, 2021 CAD Commands 0 2117

The **VSLIDE** command is used to display the slide file in current viewport.

Command Access:

Command: VSLIDE

Function Description:

Users could see the slide image that hatched by "-SHADE" command, if the current viewport is larger than the created slide viewport or the resolution in current viewport is higher than it in slide viewport, there may appear some scattered distribution black lines in images. To avoid this situation, when creating slide file, users should set full screen and the highest resolution.

Online URL: https://www.kb2.gstarcad.com.my/article.php?id=2435