


# Create Angular Dimensions

2570 GstarCAD MY /KW November 9, 2021 [Workflow](#) 0 2762

Angular dimensions measure the angle between two lines or three points. You can also measure angle of an arc or angle between two radius of circle. You can add a baseline dimension or a continued dimension after you created an angular dimension.



Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=2570>