

# Modify Dimension Style

2572 GstarCAD MY /KW November 9, 2021 [Workflow](#) 0 2731

If you need to modify properties of existing dimensions, you can use modify dimension style ([DIMSTYLE](#)). The properties of any selected dimension can be modified by [PROPERTIES](#) pallet.

## Override a Dimension Style

Dimension style overrides can be identified for individual dimensions or for the current dimension style.

To set up dimension style overrides, you can modify the options in the Dimension Style Manager dialog box or change the system variable settings at the command prompt. The override is applied to all newly created dimension until you reverse the override or make another dimension style current.

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=2572>