

# Explode Attribute to Text

Explode blocks, converting value of attributes to text objects.

**Menu** : Express>Blocks>Explode Attributes to Text

**Command Entry** : [BURST](#)


Command line prompts as follows:

**Select entities** : Use an object selection method


**For example** :

Explode attributes and convert them to text objects.

1. Select a block containing two attributes:



2. Block exploded and attribute values converted to text:



Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=2604>