Change Character

2649 GstarCAD MY /KW November 12, 2021 Workflow 0 1861

This function can continuously revise multiple text objects, single line and Mtext are applicable.

Menu: Express>Text Tools>Others>Change Character

Command Entry: CHGTXT

Operation steps:

- 1.Start the command.
- 2. Select the text to be replaced.
- 3.Input characters to replace.

Online URL: https://www.kb2.gstarcad.com.my/article.php?id=2649