

Change Character

2649 GstarCAD MY /KW November 12, 2021 [Workflow](#) 0 1992

This function can continuously revise multiple text objects, single line and Mtext are applicable.

Menu : Express>Text Tools>Others>Change Character

Command Entry : CHGTXT

Operation steps:

1. Start the command.
2. Select the text to be replaced.
3. Input characters to replace.

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=2649>