

# Global Attach Leader to Annotation

2662 GstarCAD MY /KW November 15, 2021 [Workflow](#) 0 1504

Globally attaches leaders line to mtext, tolerance, or block reference objects

**Menu** : Express>Dimension>Global Attach Leader to Annotation

**Command Entry** : QLATTACHSET


Select objects: Select one or multiple leader lines and annotation objects

Usage Example:

Select leader line(s), and mtext objects to attach.

Select objects: Select one or multiple leader lines and annotation objects, the command line prompts: Number of unlocked leaders = 2, Number with annotation detached = 2

Leader with detached mtext object:



Leader attached to mtext object:



ATTACH LEADERS TO MTEXT OR  
TOLERANCE OBJECT



ATTACH LEADERS TO BLOCK  
REFERENCE OBJECT

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=2662>