Get Selection by Layer

You can use this function to select all the objects in specified layer and specified region at one time.

Menu : Express>Selection Tools>Get Selection by Layer

Command Entry : ETLAYSEL

Operation steps:

1.Start the command.

2.Specify an entity which is in the target layer.

3.Specify region.

4.System will select all the objects in specified layer and specified region.