Add Column

2703 GstarCAD MY /KW December 2, 2021 [Workflow](#) 0 2451

This function can add new columns to the table.

Menu : Express>Table Tools>Add Column

Command Entry : BGZL

Operation steps:

1. Start the command.

2. Specify the direction of the new column as shown below.

3. The system will add a new column on the right side of the table as shown below.