

Show and Hide Raster Image Boundaries — GstarCAD 2027

2831 kbadmin September 25, 2026 [User Guide](#) 0 10

Show and Hide Raster Image Boundaries

[GstarCAD 2027](#) · [User Guide](#)

User Guide > Raster Images > Show and Hide Raster Image Boundaries

If you hide an image boundary, the boundary can not be plotted or displayed and can not be selected with the pointing device, which prevents that the image is accidentally moved or modified. Clipped images are still displayed to their specified boundary limits, when image boundaries are hidden, only the boundary is affected.

Note: When an image frame is turned off, you cannot select images using the Pick or the Window SELECT options.

Other versions with matching text

[2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=2831>