

REVCLLOUDGRIPS System Variable — GstarCAD 2027

REVCLLOUDGRIPS System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > R System Variables > REVCLLOUDGRIPS

Function Description:

The REVCLLOUDGRIPS system variable is used to control the number of grips displayed on a revision cloud.

Type	Switch
Saved in	Registry
Initial value	1
Range	0,1

System Variable Value:

- 0:**
Displays a grip for each arc segment on a revision cloud
- 1:**
Displays limited number grips on a revision cloud

Other versions with matching text

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=2938>