

QTEXT Command — GstarCAD 2027

2955 kbadmin · September 25, 2026 [Command Reference](#) 0 5

QTEXT Command

[GstarCAD 2027](#) · [Command Reference](#)

Commands > Q Command > QTEXT

Function Description:

This command is used to control the display and plotting of text and its properties. If the QTEXT is in ON mode, all text objects and their properties objects are displayed as a bounding box around the text object. Under this mode, it can save a lot of time to regenerate drawings with a large number of text objects. Uses the REGEN command to display the results of QTEXT on existing text.

Command Access:

Icon: /

Menu: /

Ribbon: /

Toolbar: /

Command: QTEXT

Alias: /

Command Prompts:

Enter mode [ON/OFF] <Off>:

Related References[?]

- [Commands about Creating Text](#)
- [Commands about Controlling Object Display](#)

Related Tasks[?]

- [To Create Texts](#)
- [To Set the Current Text Style](#)
- [To Turn On or Off the Display of Solid Fills](#)
- [To Turn On or Off the Display of Text](#)

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=2955>