

BGRIPOBJCOLOR System Variable — GstarCAD 2027

BGRIPOBJCOLOR System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > B System Variables > BGRIPOBJCOLOR

Function Description:

The BGRIPOBJCOLOR system variable is used to set the grip color in block editor.

Type	Strings
Saved in	Registry
Initial value	141
Range	1 ~ 255

The valid value of BGRIPOBJCOLOR system variable includes BYLAYER, BYBLOCK, and integers from 1 to 255.

The True color is a strings with RGB in front and each value is separated by a comma. It is entered as the following way: RGB:000,000,000

Other versions with matching text

[2016](#) · [2017](#) · [2018](#) · [2019](#) · [2020](#) · [2021](#) · [2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)