

BLOCKEDITLOCK System Variable — GstarCAD 2027

3087 kbadmin September 25, 2026 [System Variable Reference](#) 0 8

BLOCKEDITLOCK System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > B System Variables > BLOCKEDITLOCK

Function Description:

The BLOCKEDITLOCK system variable is forbid to open block editor or edit dynamic block definition.

Type	Integer
Saved in	Registry
Initial value	0
Range	0,1

System Variable Value:

0:allow to open block editor
1: forbid to open block editor
When set the BLOCKEDITLOCK system variable to be 1, it displays the "Properties" palettes by double-clicking the dynamic block.
If it contained attributes in the block ,double-clicking the dynamic block can open the "Enhanced Attribute Editor" dialog box.

Other versions with matching text

[2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=3087>