

# BPARAMETERCOLOR System Variable — GstarCAD 2027

3089 kbadmin September 25, 2026 [System Variable Reference](#) 0 16

## BPARAMETERCOLOR System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > B System Variables > BPARAMETERCOLOR

### Function Description:

The BPARAMETERCOLOR system variable is used to set parameter color in block editor.

|               |          |
|---------------|----------|
| Type          | Strings  |
| Saved in      | Registry |
| Initial value | 170      |
| Range         | 1 ~ 255  |

The valid value includes BYLAYER, BYBLOCK, and integers from 1 to 255.  
The True color is a strings with RGB in front and each value is separated by a comma. It is entered as the following way: RGB:000,000,000

### Other versions with matching text

[2016](#) · [2017](#) · [2018](#) · [2019](#) · [2020](#) · [2021](#) · [2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=3089>