

UPDATEOLEPATHBYFOLDER? System Variable — GstarCAD 2027

3113 kbadmin September 25, 2026 [System Variable Reference](#) 0 16

UPDATEOLEPATHBYFOLDER? System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > U System Variables > UPDATEOLEPATHBYFOLDER

Function Description:

The UPDATEOLEPATHBYFOLDER system variable is used to control OLE link file finding logic.

Type	Integer
Saved in	Registry
Initial value	0

System Variable Value:

- 0:** Prioritizes the search for the corresponding external file according to the link path saved in the database.
- 1:** Priority is given to finding external files in the same directory as the drawing file to link to.

Other versions with matching text

[2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=3113>