

VIEWPORTSSYNCMODE System Variable — GstarCAD 2027

3139 kbadmin September 25, 2026 [System Variable Reference](#) 0 6

VIEWPORTSSYNCMODE System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > V System Variables > VIEWPORTSSYNCMODE

Function Description:

The VIEWPORTSSYNCMODE system variable is used to control whether to display real-time preview effects in all viewports.

Type	Integer
Saved in	Register
Initial value	0
Range	0,1

System Variable Value:

- 0:** Displays only in the active viewport.
- 1:** Displays real-time effects synchronously across all viewports.

Other versions with matching text

[2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=3139>