

FACETERMAXEDGELENGTH System Variable — GstarCAD 2027

3158 kbadmin September 25, 2026 [System Variable Reference](#) 0 9

FACETERMAXEDGELENGTH System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > F System Variables > FACETERMAXEDGELENGTH

Function Description:

The FACETERMAXEDGELENGTH system variable is used to set the maximum length of mesh object edge when converting from solids or surfaces to mesh objects.

Type	Real
Saved in	User-settings
Initial value	0.0000

The FACETERMAXEDGELENGTH system variable can be a any non-negative, including 0.
Note: this system variable reflects the absolute value of objects whose smoothness is zero.

Other versions with matching text

[2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=3158>