

FACETERMINVGRID System Variable — GstarCAD 2027

3162 kbadmin September 25, 2026 [System Variable Reference](#) 0 5

FACETERMINVGRID System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > F System Variables > FACETERMINVGRID

Function Description:

The FACETERMINVGRID system variable is used to set internal parameters.

Type	Integer
Saved in	User-settings
Initial value	0
Range	0 ~ 1023

The value of FACETERMINUGRID can not be larger than FACETERMAXGRID.

Other versions with matching text

[2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=3162>