

FILEDIA System Variable — GstarCAD 2027

FILEDIA System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > F System Variables > FILEDIA

Function Description:

The FILEDIA system variable is used to control whether display the file navigation dialog boxes or not.

Type	Integer
Saved in	Registry
Initial value	1
Range	0,1

System Variable Value:

- 0:** do not display dialog box. Users can apply to display file dialog box by entering a tide "~" under command prompts
- 1:** display dialog box. It may display an ordinary prompt when a script program is active.

Other versions with matching text

[2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=3169>