

FILLETRAD System Variable — GstarCAD 2027

FILLETRAD System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > F System Variables > FILLETRAD

Function Description:

The FILLETRAD system variable is used to store the current fillet radius for 2D objects.

Type	Real
Saved in	Drawing
Initial value	0.0000

If modified 2D fillet radius by FILLET command, the value of FILLETRAD system variable will change to match its radius value.

Other versions with matching text

[2016](#) · [2017](#) · [2018](#) · [2019](#) · [2020](#) · [2021](#) · [2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)