

ACTUI System Variable — GstarCAD 2027

ACTUI System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > A System Variables > ACTUI

Function Description:

The ACTUI system variable is used to control the behavior of Action Recorder panel when recording and playing back macros.

Type	Bitcode
Saved in	Registry
Initial value	6
Range	0 ~ 7

System Variable Value:

- 0:** no changes occurs on Action Recorder panel when recording and playing back macros
- 1:** unfold Action Recorder panel when playing back macros
- 2:** unfold Action Recorder panel when recording macros
- 4:** prompt users to input name and description for action macros when finishing recording

Other versions with matching text

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=3234>