

OSNAP Command — GstarCAD 2027

3305 kbadmin September 25, 2026 [Command Reference](#) 0 21

OSNAP Command

[GstarCAD 2027](#) · [Command Reference](#)

Commands > O Command > OSNAP

Function Description:

This command is used to set running object snap modes. The Object Snap tab of the Drafting Settings dialog box is displayed. If you enter -OSNAP at the Command prompt, options are displayed.

Command Access:

Menu: Tools > Drafting Settings > ...

Ribbon: /

Toolbar: OSNAP > Osnap Settings

Command: OSNAP

Alias: OS

Shortcut: Press SHIFT key and right-click, select Osnap Settings...

Command Prompts:

Related References[?]

- [Commands about Object Snap](#)

Related Tasks[?]

- [To Display the Object Snap Menu](#)
- [To Set Running Object Snaps](#)

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=3305>