

MTEXTTOOLBAR System Variable — GstarCAD 2027

MTEXTTOOLBAR System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > M System Variables > MTEXTTOOLBAR

Function Description:

The MTEXTTOOLBAR system variable is used to control the display of text formatting toolbar.

Type	Integer
Saved in	Users-setting
Initial value	1
Range	0,1,2

System Variable Value:

- 0:** never display the text formatting toolbar
- 1:** display the text formatting toolbar after selecting MTEXT objects
- 2:** display the text formatting toolbar when the ribbon is on❓not support❓

Other versions with matching text

[2016](#) · [2017](#) · [2018](#) · [2019](#) · [2020](#) · [2021](#) · [2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=3335>