

GRIPHOVER System Variable — GstarCAD 2027

3416 kbadmin September 25, 2026 [System Variable Reference](#) 0 12

GRIPHOVER System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > G System Variables > GRIPHOVER

Function Description:

The GRIPHOVER system variable is used to control the hatch color of grips when the cursor temporarily hover on it without selection.

Type	Integer
Saved in	Registry
Initial value	11
Range	1 ~ 255

Other versions with matching text

[2016](#) · [2017](#) · [2018](#) · [2019](#) · [2020](#) · [2021](#) · [2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=3416>