

GRIPMULTIFUNCTIONAL System Variable — GstarCAD 2027

3417 kbadmin September 25, 2026 [System Variable Reference](#) 0 10

GRIPMULTIFUNCTIONAL System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > G System Variables > GRIPMULTIFUNCTIONAL

Function Description:

The GRIPMULTIFUNCTIONAL system variable is used to control the access way for multiple function grip option.

Type	Bitcode
Saved in	Registry
Initial value	3
Range	0,1,2,3

System Variable Value:

- 0:** the multiple function grip option is disabled
- 1:** access multiple function grip option by CTRL to change grip behaviors(cycle change object editing ways by pressing CTRL key)
- 2:** access multiple function grip option by displaying grip menu when cursor hovering on grips
- 3:** access multiple function grip option by CTRL or displaying grip menu

Other versions with matching text

[2016](#) · [2017](#) · [2018](#) · [2019](#) · [2020](#) · [2021](#) · [2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=3417>