

TCASE Command — GstarCAD 2027

3469 kbadmin September 25, 2026 [Command Reference](#) 0 11

TCASE Command

[GstarCAD 2027](#) · [Command Reference](#)

Commands > T Command > TCASE

Function Description:

This command is used to change the case of selected text, mtext, attributes, and dimension text. After you select an object and press Enter, the TCASE dialog box is displayed.

Command Access:

Menu: Text > Change Text Case

Ribbon: /

Toolbar: /

Command: TCASE

Alias: /

Command Prompts:

Select object:

Other versions with matching text

[2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=3469>