

RESETBLOCK Command — GstarCAD 2027

3517 kbadmin September 25, 2026 [Command Reference](#) 0 12

RESETBLOCK Command

[GstarCAD 2027](#) · [Command Reference](#)

Commands > R Command > RESETBLOCK

Function Description:

This command is used to reset one or more dynamic block references to the default values of the block definition.

Command Access:

Icon: /

Menu: /

Ribbon: /

Toolbar: /

Command: RESETBLOCK

Alias: /

Shortcut: Select one dynamic block reference, right-click and select Reset Block

Command Prompts: /

Related References?

- [Commands about Dynamic Blocks](#)

Related Tasks?

- [To Create Dynamic Blocks](#)

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=3517>