

RTEDIT Command — GstarCAD 2027

3528 kbadmin September 25, 2026 [Command Reference](#) 0 7

RTEDIT Command

[GstarCAD 2027](#) · [Command Reference](#)

Commands > R Command > RTEDIT

Function Description:

This command is used to edit existing remote text (rtext) objects.
Uses the RTEXT command to create rtext objects.

Command Access:

Menu: Text > Change RText

Ribbon: Annotation > Text > Change RText

Toolbar: ET: Texts Tools > Change RText

Command: RTEDIT

Alias: /

Command Prompts:

Select an RText:

Style

Specifies a new style for the rtext object.

Height

Specifies a new height for the rtext object.

Rotation

Specifies a new rotation for the rtext object.

Edit

Opens the editor in which you can edit the rtext.

Related Tasks?

- [To Work With Express Tools](#)

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=3528>