

TDINDWG System Variable — GstarCAD 2027

TDINDWG System Variable

[GstarCAD 2027](#) · [System Variables](#)

System Variables > T System Variables > TDINDWG

Function Description:

The TDINDWG system variable is used to store the total editing time which is the total elapsed time between saves of current drawing.
(Read-Only)

Type	Real
Saved in	Drawing
Initial value	Unknown

The format is:

<number of day>.<decimal fraction of a day>

To compute the number of seconds, multiply the decimal fraction in TDINDWG by 86400 seconds.

Other versions with matching text

[2016](#) · [2017](#) · [2018](#) · [2019](#) · [2020](#) · [2021](#) · [2022](#) · [2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=3579>