

MININSERT Command — GstarCAD 2027

3627 kbadmin · September 25, 2026 [Command Reference](#) 0 3

MININSERT Command

[GstarCAD 2027](#) · [Command Reference](#)

Commands > M Command > MININSERT

Function Description:

This command is used to insert multiple instances of a block in a rectangular array. Before specifying the position of the insertion point, options preset the scale and rotated angle of a block. Presetting is useful for dragging a block using a scale factor and a rotation rather than 1 or 0. Users can specify a distance for the scale options or an angle for rotation. Blocks inserted using the MININSERT command can not be exploded. You can not use the MININSERT command with annotative blocks.

Command Access:

Icon: /
Menu: /
Ribbon: /
Toolbar: /
Command: MININSERT
Alias: /

Command Prompts:

Enter block name or [?] <1>:

Enter block name

Enter the name of the block to be arrayed. You can enter (tilde) at the prompt to display the Select Drawing File dialog box.

?

The gcad Text Window is displayed, which lists the currently defined blocks in the drawing.

Related References[?]

- [Commands about Arrays](#)

Related Tasks[?]

- [To Insert a Block](#)
- [To Work With Rectangular Arrays](#)
- [To Work With Path Arrays](#)
- [To Work With Polar Arrays](#)

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=3627>